

X-Cel / IRAY Wireless retrofit setup guide

1. Remove outside of double sided tape on blocks and insert into sides of base:



2. Remove outside of double sided tape on base inserts and inset into sides of panel enclosure:



Completed Retrofit setup:

